


MSA FORMULA PARTS CATALOGUE






Parts Catalogue V 1.5

M14-F4 Ford


SUMMARY

PAGE	
4	ENGINE
6	PEDAL BOX
14	GEARBOX / CLUTCH SYSTEM
20	FRONT SUSPENSION
32	REAR SUSPENSION
44	STEERING
48	BRAKE HYDRAULICS
50	MONOCOQUE
54	SAFETY ACCESSORIES
62	COOLING SYSTEM
72	ELECTRICAL LOOM DATA ACQUISITION
80	GEAR SHIFT
88	FUEL SYSTEM
82	BODYWORK
100	WINGS
102	TOOLING




Engine equipment Ford

N°	Reference	Description	Qty	Ford	Type
1	F.41.10.088.A	Lower engine stud, outer, Ford engine	2	x	1
2	F.41.10.089.A	Lower engine stud, right inside, Ford engine	1	x	1
3	F.41.10.090.A	Lower engine stud, left inside, Ford engine	1	x	1
4	F.41.10.091.A	Dowel, monocoque-engine bracket	4	x	1
5	F.41.10.069.A	Engine frame, Ford engine, left	1	x	1
7	F.41.10.094.B	Exhaust, Ford engine	1	x	1
8	F.41.21.075.A	ECU support, Ford	1	x	1
9	F.41.21.076.A	Bridge, ECU support, Ford	1	x	1
10	F.41.10.070.A	Engine frame, Ford engine, right	1	x	1
11	AVM01.05.0012	Screw CHC M5x12 cl 12.9	2	x	3
12	AVM04.06.0035	Screw TFHC M6x35 cl 10.9	4	x	3
13	ARO06.05.0001	Washer small Ø5 ZnBl	2	x	3
14	ARO06.06.0001	Washer small Ø6 ZnBl	4	x	3
15	AEM01.06.0001	Nylstop nut M6 ZnBl	4	x	3
16	AVM01.08.0035	Screw CHc M8x35 cl 12.9	6	x	3
17	AVM01.08.0050	Screw CHC M8x50 cl 12.9	3	x	3
18	AVM01.10.0040	CHC Screw M10x40 cl 12.9	2	x	3
19	AEM06.10.0001	K-nut M10	4	x	3
20	ARO06.08.0001	Washer small Ø8 ZnBl	3	x	3
21	ARO06.10.0001	Washer small Ø10 ZnBl	2	x	3
22	ARO13.08.0001	Washer Schnorr Ø8	9	x	3
23	ARO13.10.0001	Washer Schnorr Ø10	2	x	3
25	ARO02.10.0001	Plate medium washer Ø10x22	4	x	3




Pedal box

N°	Reference	Description	Qty	Ford	Type
2	F.41.11.002.A	Pedal box shaft	1	x	1
4	F.41.11.007.A	Sleeve nut, pedal box	3	x	1
8	F.41.11.024.A	Clutch pedal rest	1	x	2
9	F.41.11.026.B	Brake pedal rest	1	x	2
10	F.41.11.003.B	Throttle pedal rest	1	x	3
17	F.41.11.017.C	Master cylinder rod prolongator (setting 1)	3	Option	1
18	F.41.11.018.C	Master cylinder rod prolongator (setting 2)	3	x	1
19	F.41.11.019.C	Master cylinder rod prolongator (setting 3)	3	Option	1
20	F.41.11.020.C	Master cylinder rod prolongator (setting 4)	3	Option	1
21	F.41.11.021.C	Master cylinder rod prolongator (setting 5)	3	Option	1
22	F.41.11.029.B	Short spacer pedal stop	2	Option	1
24	F.41.11.031.A	Short pedal stop rest	1	Option	1
25	F.41.11.032.A	Long pedal stop rest	1	Option	2
26	F.41.11.009.A	Brake bias	1	x	1
28	F.41.11.011.A	Sleeve nut, brake bias	1	x	1
29	F.41.11.043.A	Brake bias cable	1	x	1
31	F.41.11.045.A	Foot wedge	1	Option	3
32	F.41.11.047.A	Pedal board support	1	x	1
33	F.41.11.055.A	Clutch pedal	1	x	1
34	F.41.11.048.A	Brake pedal	1	x	1
35	F.41.11.050.B	Throttle pedal	1	x	1
36	F.41.11.053.A	Spacer throttle pedal 29mm	1	x	1
38	F.41.11.051.A	Throttle cable fixing	1	x	1
39	ACA.06.04.0001	Cable clamp Ø4xØ12 long26	1	x	1
41	F.41.11.054.A	Pedal stop	2	x	1
42	F.41.11.056.A	Long spacer pedal stop	2	x	1
43	F.41.11.049.A	Clutch pedal fork end	1	x	1
44	ARO.04.10.1001	Flat washer Ø10xØ36x2	2	x	3




Pedal box

N°	Reference	Description	Qty	Ford	Type
45	F.41.11.052.A	Throttle pedal front stop	1	x	1
46	AVM01.06.0016	Screw CHC M6x16 cl 12.9	6	x	3
47	ARO06.06.0001	Washer small Ø6 ZnBl	12	x	3
48	AVM01.06.0012	Screw CHc M6x12 cl 12.9	3	Option	3
50	AVM01.04.0010	Screw CHC M4x10 cl 12.9	2	x	3
51	AVM04.05.0016	Screw TFHC M5x16 cl 10.9	9	x	3
52	AVM01.06.0020	Screw CHC M6x20 cl 12.9	1	x	3
53	AVM04.06.0020	Screw TFHC M6x20 cl 10.9	1	x	3
54	AVM01.04.0016	Screw CHC M4x16 cl 12.9	2	x	3
55	AVM01.08.4526	Screw CHC M8x45 ct 26 cl 12.9	1	x	3
56	AVM01.08.0030	Screw CHc M8x30 cl 12.9	2	x	3
57	AEM01.06.0001	Nylstop nut M6 ZnBl	2	x	3
58	AEM01.08.0001	Nylstop nut M8 ZnBl	1	x	3
59	ARO13.08.0001	Washer Schnorr Ø8	1	x	3
60	ARO06.08.0001	Washer small Ø8 ZnBl	3	x	3
61	ARO07.04.0001	Washer medium Ø4x10 ZnBl	2	x	3
62	ACA.01.06.06.2500	Accelerator cable Ø6x6 long 2.5m	1	x	2
63	AVM04.04.0016	Screw TFHC M4x16 cl 10.9	2	x	3
65	AEM02.06.0001	ISO 4035 nut M6	1	x	3
66	AVM01.06.0030	Screw CHC M6x30 cl 12.9	1	x	3
67	AEM02.08.0001	ISO 4035 nut M8	2	x	3
68	AVM05.05.0006	Without Head Screw HC M5x6	2	x	3
69	F.41.11.057.A	Spacer, brake bias adjuster 100mm	1	Option	2




Pedal box "small driver"

N°	Reference	Description	Qty	Ford	Type
1	F.41.11.059.A	Plate, pedal box offset	2	Option	1
2	F.41.11.060.A	Long spacer throttle pedal 55mm	1	Option	1
3	F.41.11.061.A	Master cylinder rod prolongator 300mm	3	Option	1
4	F.41.11.062.A	Spacer pedal stop 215mm	2	Option	1
5	F.41.21.105.A	Bracket, throttle sensor, pedal box offset	1	Option	1
6	F.41.21.106.A	Bush, throttle sensor, pedal box offset	2	Option	1




Master cylinder assy

N°	Reference	Description	Qty	Ford	Type
1	F.41.12.001.A	Reservoir, master cylinder, clutch	1	x	1
5	F.41.12.005.A	Girling master cylinder 3/4 (clutch)	1	x	1
7	F.41.12.124.A	Adaptor, clutch resevoir	1	x	1
8	F.41.12.026.A	hose, clutch reservoir	1	x	3
9	F.41.17.017.A	Rear brake master cylinder 3/4 with tank	1	x	1
11	F.41.17.018.A	Front brake master cylinder 5/8 with tank	1	x	1
12	F.41.12.055.A	Spacer clutch master cylinder	2	x	1
13	AVM01.08.0035	Screw CHc M8x35 cl 12.9	2	x	3
14	AVM01.08.0030	Screw CHc M8x30 cl 12.9	4	x	3
15	ARO13.08.0001	Washer Schnorr Ø8	6	x	3
16	ACO02.08.0016	Collar Tie Clips Ø8-16	2	x	3
18	AEF02.51.6001	Nut 5/16 UNF ZnBI	3	x	3
20	AJO01.04.0001	Copper Seal 7/16	1	Spare	3




Driveshaft

N°	Reference	Description	Qty	Ford	Type
1	F.41.12.017.A	Complete driveshaft	2	x	1
2	F.41.12.050.A	CV joint, driveshaft, wheel side	2	Spare	1
3	F.41.12.051.A	CV boot, driveshaft, wheel side + fixings	2	Spare	1
4	F.41.12.052.A	Driveshaft	2	Spare	1
5	F.41.12.053.A	Tripod flange, gearbox	2	Spare	1
6	F.41.12.054.A	Tripod, gearbox	2	Spare	1
7	F.41.12.103.A	Flange closing plate	2	Spare	1
8	F.41.12.104.A	Rubber	2	Spare	1
9	F.41.12.105.A	Rubber plate	2	Spare	1
10	F.41.12.106.A	Ø86x3 O'ring	2	Spare	3
11	F.41.12.107.A	SB31 circlip	2	Spare	3
12	F.41.12.108.A	H26 circlip	2	Spare	3
13	F.41.12.109.A	M5x25 CHC bolt	6	Spare	3
14	F.41.12.110.A	M5x16 FHC bolt	6	Spare	3
15	F.41.12.126.A	Pin, CV boot	4	Spare	3
16	F.41.12.127.A	Grease (120 gr)	-	Spare	3
17	F.41.12.131.A	Grease (400 gr)	-	Spare	3
18	F.41.12.130.A	Ø32.4x1.9 Ring	2	Spare	3
19	F.41.12.132.A	Drive shaft stop	2	Spare	1




Bell housing Ford

N°	Reference	Description	Qty	Ford	Type
1	F.41.12.058.A	Bell housing machining - Ford engine	1	x	1
2	F.41.12.064.A	Belhousing plate, Ford	1	x	1
3	F.41.12.049.A	Dowel bellhousing to gearbox	2	x	1
4	F.41.12.062.C	Belhousing bracket, Ford	1	x	1
5	F.41.12.063.A	Spacer belhousing bracket, Ford	2	x	1
6	F.41.12.065.A	Centring bush, bell housing, Ford	2	x	1
7	F.41.12.074.A	Engine-bellhousing dowel Ford	2	x	1
8	F.41.12.076.B	Spacer, clutch release, Ford	1	x	1
9	AVM01.08.0030	Screw CHc M8x30 cl 12.9	6	x	3
12	AVM01.10.0050	CHC Screw M10x50 cl 12.9	3	x	3
13	AVM01.10.0060	Screw CHC M10x60 cl 12.9	4	x	3
15	AVM04.04.0008	Screw TFHC M4x8 cl 10.9	4	x	3
16	AEM01.10.0001	Nylstop nut M10 ZnBl	4	x	3
17	ARO06.10.0001	Washer small Ø10 ZnBl	4	x	3
18	ARO13.08.0001	Washer Schnorr Ø8	6	x	3
19	ARO13.10.0001	Washer Schnorr Ø10	15	x	3
21	F.41.12.067.C	Stud, gearbox to bell housing, Ford	4	x	1
22	AVM01.10.0045	Screw CHc M10x45 cl 12.9	1	x	3
23	AVM01.10.0055	Screw CHc M10x55 cl 12.9	1	x	3
24	AVM01.10.0035	Screw CHc M10x35 cl 12.9	6	x	3




Clutch hydraulics

N°	Reference	Description	Qty	Ford	Type
1	F.41.12.014.A	Clutch release bearing	1	x	1
2	F.41.12.015.A	Clutch release	1	x	1
3	F.41.12.030.B	Clutch line, slave cylinder	1	x	1
4	F.41.12.031.B	Clutch line, main	1	x	1
5	F.41.12.032.C	Clutch line, bleed	1	x	1
6	AVM01.06.0035	Screw CHC M6x35 cl 12.9	3	x	3
7	ARO13.06.0001	Washer Schnorr Ø6	3	x	3
8	F.41.12.020.A	Seals set, clutch release	1	Spare	3
9	AJO01.10.0002	Copper Seal Ø10	1	Spare	3
10	AJO02.12.0001	Aluminium seal Ø12	2	Spare	3




Front suspension

N°	Reference	Description	Qty	Ford	Type
1	F.41.14.004.A	Bracket, anti-roll bar	2	x	1
4	F.41.14.002.A	Washer, anti-roll bar	2	x	1
5	F.41.14.005.A	Front link adjuster	2	x	1
6	F.41.14.030.B	Bracket, front damper	2	x	1
8	ART04.05.0001	RH Rod end Bearing size 5	2	x	3
9	ART05.05.0001	LH Rod end Bearing size 5	2	x	3
10	ADA05.12.0001	Combined Needle Bearing Ø12	2	x	1
13	F.41.14.022.A	Spring 600 lbs/in	2	Option	1
15	F.41.14.024.A	Spring 800 lbs/in	2	x	1
17	F.41.14.026.A	Spring 1000 lbs/in	2	Option	1
18	F.41.14.100.A	Adjustment clevis, anti-roll bar	2	x	1
19	F.41.14.103.A	Sachs Front Damper, non adjustable	2	x	1
23	F.41.14.107.B	Anti roll bar D14	1	x	1
24	AVM01.06.0016	Screw CHC M6x16 cl 12.9	4	x	3
25	ARO13.06.0001	Washer Schnorr Ø6	4	x	3
26	AVM04.06.0020	Screw TFHC M6x20 cl 10.9	4	x	3
27	AEF02.38.0001	Nut 3/8 UNF ZnBl	2	x	3
28	AEF04.38.0001	Nut 3/8 UNF Left thread ZnBl	2	x	3
31	ARO06.08.0001	Washer small Ø8 ZnBl	8	x	3
32	AEM01.08.0001	Nylstop nut M8 ZnBl	4	x	3
35	AVM01.08.5035	Screw CHC M8x50 ct 35 cl 12.9	2	x	3
36	AVM01.08.6042	Screw CHc M8x60 ct42 cl 12.9	2	x	3
37	F.41.14.108.A	Set screw anti roll bar	2	x	3
38	F.41.14.111.B	Anti roll bar D18	1	Option	1
39	F.41.14.114.B	Anti roll bar D12	1	Option	1




Front rocker

N°	Reference	Description	Qty	Ford	Type
1	F.41.14.020.A	Rocker washer	4	x	1
2	F.41.14.018.A	Rocker hub	2	x	1
3	F.41.14.008.B	Upper plate, front rocker	2	x	1
4	F.41.14.009.C	Lower plate, front rocker, left	1	x	1
5	F.41.14.010.C	Lower plate, front rocker, right	1	x	1
6	F.41.14.011.A	Front rocker shaft	2	x	1
7	F.41.14.015.A	Needle bearing	4	x	1
8	F.41.14.016.A	Rocker shim	4	x	1
9	F.41.14.014.A	Rocker bush	2	x	1
10	F.41.14.017.A	Needle bearing	2	x	1
11	F.41.14.019.A	Adjusting shim	-	x	3
12	F.41.14.012.A	Rocker spacer	6	x	1
13	F.41.14.069.B	Spacer, damper	4	x	1
14	F.41.14.013.A	Rocker spacer, lower front	2	x	1
16	AVM04.06.5040	Screw TFHC M6x50 ct 40 cl 10.9	6	x	3
19	ARO06.08.0001	Washer small Ø8 ZnBl	10	x	3
20	ARO06.06.0001	Washer small Ø6 ZnBl	6	x	3
21	ARO13.10.0001	Washer Schnorr Ø10	2	x	3
22	AEM06.10.0001	K-nut M10	2	x	3
23	AEM01.08.0001	Nylstop nut M8 ZnBl	6	x	3
24	AEM01.06.0001	Nylstop nut M6 ZnBl	6	x	3
25	AVM04.08.5042	Screw TFHc M8x50 ct 42 cl 10.9	2	x	3
27	AVM01.10.7558	Screw CHc M10x75 ct 58 cl 12.9	2	x	3
28	AVM01.08.6042	Screw CHc M8x60 ct42 cl 12.9	4	x	3




Front corner

N°	Reference	Description	Qty	Ford	Type
1	F.41.14.083.C	Front lower wishbone, with spherical bearing, left	1	x	1
2	F.41.14.084.C	Front lower wishbone, with spherical bearing, right	1	x	1
3	F.41.14.086.A	Front pushrod	2	x	1
4	F.41.14.085.A	Front upper wishbone	2	x	1
5	F.41.14.087.A	Steering track rod	2	x	1
6	F.41.14.062.A	Suspension bracket	8	x	1
7	F.41.14.028.A	Adjuster	2	x	1
8	F.41.14.063.B	Spacer, suspension bearing	16	x	1
9	ACI04.30.0001	Inverted Internal Circlips Ø30	2	Spare	3
10	ART02.10.0001	Spherical Bearing Dash 10	2	Spare	3
11	ART05.05.0001	LH Rod end Bearing size 5	2	x	3
12	ART04.05.0001	RH Rod end Bearing size 5	2	x	3
13	F.41.14.075.B	Bush, front wishbone bracket	8	x	1
14	AEF02.12.0001	Nut 1/2 UNF ZnBl	2	x	3
15	AEF02.38.0001	Nut 3/8 UNF ZnBl	2	x	3
16	AEF04.38.0001	Nut 3/8 UNF Left thread ZnBl	2	x	3
18	AVM01.08.0030	Screw CHc M8x30 cl 12.9	8	x	3
19	AVM01.08.0020	Screw CHC M8x20 cl 12.9	8	x	3
20	ARO13.08.0001	Washer Schnorr Ø8	16	x	3
21	ARO06.08.0001	Washer small Ø8 ZnBl	16	x	3
22	AEM01.08.0001	Nylstop nut M8 ZnBl	8	x	3
23	AVM01.08.6042	Screw CHc M8x60 ct42 cl 12.9	8	x	3
24	F.41.14.116.B	Front lower wishbone, left, assembly with brake line	1	Assembly part	1
25	F.41.14.117.B	Front lower wishbone, right, assembly with brake line	1	Assembly part	1
26	F.41.14.118.A	Front pushrod assembly	2	Assembly part	1
27	F.41.14.119.A	Steering track rod assembly	2	Assembly part	1
29	F.41.14.121.A	Staking bearing joint replacement	1	Repair	1
30	ART02.05.0001	Spherical Bearing Dash 5	1	Spare	1
31	F.41.14.122.A	Staking bearing housing replacement	1	Repair	1




Front upright

N°	Reference	Description	Qty	Ford	Type
1	F.41.14.032.D	Upright	2	x	1
2	F.41.14.029.A	Wheel bearing	2	x	1
3	F.41.17.001.A	Brake disc	2	x	1
4	F.41.14.065.A	Lower upright pin	2	x	1
5	F.41.14.066.A	Lower washer, upright pin	2	x	1
6	F.41.14.097.A	Spacer, lower upright pin	2	x	1
7	F.41.14.067.A	Upper washer, upright pin	2	x	1
8	F.41.14.063.B	Spacer, suspension bearing	8	x	1
9	F.41.14.064.B	Spacer, suspension bearing, large	4	x	1
10	F.41.14.061.D	Bracket, pushrod on upright	2	x	1
11	F.41.14.060.A	Steering arm	2	x	1
12	F.41.14.055.A	Camber shim, 1 mm	2	Option	1
13	F.41.14.056.A	Camber shim, 1.5 mm	2	Option	1
14	F.41.14.057.A	Camber shim, 2 mm	2	x	1
15	F.41.14.058.A	Camber shim, 4 mm	2	Option	1
16	F.41.14.077.B	Drive peg	8	x	1
17	F.41.14.076.C	Front wheel stud	2	x	1
20	F.41.17.002.A	Brake caliper, trailing left	1	x	1
21	F.41.17.003.A	Brake caliper, trailing right	1	x	1
22	F.41.17.004.A	Brake pads, DS Performance (box of 4)	1	x	1
24	AVM01.12.7050	Screw CHc M12x70 ct50 pitch 150 cl 12.9	2	x	3
25	AVM01.12.7062	Screw CHc M12x70 ct62 pitch 150 cl 12.9	4	x	3
27	AVM01.10.0030	Screw CHc M10x30 cl 12.9	4	x	3
28	AVM01.08.6045	Screw CHc M8x60 ct45 cl 12.9	4	x	3
31	AEM01.08.0001	Nylstop nut M8 ZnBl	6	x	3
32	ARO06.08.0001	Washer small Ø8 ZnBl	12	x	3
34	ARO13.08.0001	Washer Schnorr Ø8	8	x	3
35	AVF01.38.0300	Screw CHc 3/8x3" UNF cl 12.9	2	x	3




Front upright

N°	Reference	Description	Qty	Ford	Type
36	AVM01.08.0020	Screw CHC M8x20 cl 12.9	4	x	3
37	ARO13.10.0001	Washer Schnorr Ø10	4	x	3
38	ARO13.12.0001	Washer Schnorr Ø12	6	x	3
39	AEF01.38.0001	Nylstop nut 3/8 UNF ZnBl	2	x	3
44	F.41.17.007.A	Brake pads, DS3000 (box of 4)	1	Option	1
45	F.41.17.008.A	Brake pads, DS1.11 (box of 4)	1	Option	1
49	AVM01.08.5540	Screw CHC M8x55 ct 40 cl 12.9	2	x	3
51	F.41.14.115.A	Front L/H upright pre assembly	1	Assembly part	1
52	F.41.14.120.A	Front R/H upright pre assembly	1	Assembly part	1
54	AVM04.06.0016	Screw TFHC M6x16 cl 10.9	2	x	3
55	AVM01.08.0035	Screw CHc M8x35 cl 12.9	4	x	3




Front wheel

N°	Reference	Description	Qty	Ford	Type
1	F.41.14.078.A	Front rim	2	x	1
2	F.41.14.082.A	Safety clip, wheel nut	2	x	1
3	F.41.14.079.B	Washer, wheel nut	2	x	1
4	F.41.14.080.A	Wheel nut	2	x	1
5	ACI02.24.0001	External Circlips Ø24	2	x	3
6	F.41.14.081.B	Wheel nut assy	2	Assembly part	1




Rear suspension

N°	Reference	Description	Qty	Ford	Type
1	F.41.14.004.A	Bracket, anti-roll bar	2	x	1
4	F.41.14.002.A	Washer, anti-roll bar	2	x	1
5	F.41.15.021.A	Rear link adjuster	2	x	1
6	F.41.15.022.B	Bracket, rear damper	2	x	1
8	ART04.05.0001	RH Rod end Bearing size 5	2	x	3
9	ART05.05.0001	LH Rod end Bearing size 5	2	x	3
10	ADA05.12.0001	Combined Needle Bearing Ø12	2	x	1
13	F.41.14.022.A	Spring 600 lbs/in	2	Option	1
15	F.41.14.024.A	Spring 800 lbs/in	2	x	1
17	F.41.14.026.A	Spring 1000 lbs/in	2	Option	1
18	F.41.14.100.A	Adjustment clevis, anti-roll bar	2	x	1
19	F.41.15.029.A	Sachs Rear damper, non adjustable	2	x	1
23	F.41.14.107.B	Anti roll bar D14	1	x	1
24	AVM01.06.0020	Screw CHC M6x20 cl 12.9	4	x	3
25	ARO13.06.0001	Washer Schnorr Ø6	4	x	3
26	AVM04.08.0020	Screw TFHC M8x20 cl 10.9	2	x	3
27	AVM01.08.0020	Screw CHC M8x20 cl 12.9	2	x	3
28	ARO13.08.0001	Washer Schnorr Ø8	2	x	3
31	ARO06.08.0001	Washer small Ø8 ZnBl	8	x	3
32	AEM01.08.0001	Nylstop nut M8 ZnBl	4	x	3
33	AEF02.38.0001	Nut 3/8 UNF ZnBl	2	x	3
34	AEF04.38.0001	Nut 3/8 UNF Left thread ZnBl	2	x	3
36	AVM01.08.5035	Screw CHC M8x50 ct 35 cl 12.9	2	x	3
37	AVM01.08.6042	Screw CHC M8x60 ct42 cl 12.9	2	x	3
38	F.41.14.108.A	Set screw anti roll bar	2	x	3
39	F.41.14.111.B	Anti roll bar D18	1	Option	1
40	F.41.14.114.B	Anti roll bar D12	1	Option	1




Rear rocker

N°	Reference	Description	Qty	Ford	Type
2	F.41.14.018.A	Rocker hub	2	x	1
3	F.41.15.019.A	Rear rocker plate	4	x	1
4	F.41.14.012.A	Rocker spacer	8	x	1
5	F.41.14.069.B	Spacer, damper	4	x	1
6	F.41.15.018.A	Rear axle rocker	2	x	1
7	F.41.14.015.A	Needle bearing	4	x	1
8	F.41.14.016.A	Rocker shim	4	x	1
9	F.41.14.014.A	Rocker bush	2	x	1
10	F.41.14.017.A	Needle bearing	2	x	1
11	F.41.14.019.A	Adjusting shim	-	x	3
13	F.41.15.027.A	Rear rocker stud	2	x	1
14	F.41.14.020.A	Rocker washer	2	x	1
15	AEM01.08.0001	Nylstop nut M8 ZnBl	6	x	3
16	AEM01.06.0001	Nylstop nut M6 ZnBl	6	x	3
17	AEM06.10.0001	Nut Avia M10	2	x	3
19	AVM01.06.0040	Screw CHC M6x40 cl 12.9	4	x	3
20	ARO06.06.0001	Washer small Ø6 ZnBl	12	x	3
21	ARO06.08.0001	Washer small Ø8 ZnBl	12	x	3
23	AVM07.06.0040	Screw CHC M6x40 low head cap cl10.9	2	x	3
24	AVM01.08.6042	Screw CHc M8x60 ct42 cl 12.9	6	x	3




Rear corner

N°	Reference	Description	Qty	Ford	Type
1	F.41.15.001.C	Rear lower wishbone, with spherical bearing, left	1	x	1
2	F.41.15.002.C	Rear lower wishbone, with spherical bearing, right	1	x	1
3	F.41.15.004.B	Rear pushrod	2	x	1
4	F.41.15.003.A	Rear upper wishbone	2	x	1
5	F.41.14.062.A	Suspension bracket	4	x	1
6	F.41.15.016.A	Suspension bracket, offseted	4	x	1
7	F.41.14.028.A	Adjuster	4	x	1
8	F.41.14.063.B	Spacer, suspension bearing	16	x	1
9	ACI04.30.0001	Inverted Internal Circlips Ø30	2	Spare	3
10	ART02.10.0001	Spherical Bearing Dash 10	2	Spare	3
11	ART05.05.0001	LH Rod end Bearing size 5	4	x	3
12	ART04.05.0001	RH Rod end Bearing size 5	2	x	3
17	AEM01.08.0001	Nylstop nut M8 ZnBl	10	x	3
18	ARO06.08.0001	Washer small Ø8 ZnBl	20	x	3
19	ARO13.08.0001	Washer Schnorr Ø8	16	x	3
20	AEF02.38.0001	Nut 3/8 UNF ZnBl	2	x	3
21	AEF04.38.0001	Nut 3/8 UNF Left thread ZnBl	4	x	3
22	AEF02.12.0001	Nut 1/2 UNF ZnBl	4	x	3
23	AVM01.08.6549	Screw CHc M8x65 ct49 cl 12.9	4	x	3
24	AVM01.08.6042	Screw CHc M8x60 ct42 cl 12.9	4	x	3
25	AVM01.08.4530	Screw CHC M8x45 ct 30 cl 12.9	2	x	3
26	AVM01.08.0020	Screw CHC M8x20 cl 12.9	8	x	3
27	AVM01.08.4535	Screw CHC M8x45 ct 35 cl 12.9	8	x	3
28	F.41.15.031.B	Rear lower wishbone, left, assembly with brake line	1	Assembly part	1
29	F.41.15.032.B	Rear lower wishbone, right, assembly with brake line	1	Assembly part	1
30	F.41.15.033.A	Rear pushrod assembly	2	Assembly part	1
31	F.41.15.034.A	Rear upper wishbone assembly	2	Assembly part	1
33	F.41.14.121.A	Staking bearing joint replacement	1	Repair	1
34	ART02.05.0001	Spherical Bearing Dash 5	1	Spare	1
35	F.41.14.122.A	Staking bearing housing replacement	1	Repair	1




Rear upright

N°	Reference	Description	Qty	Ford	Type
1	F.41.14.032.D	Upright	2	x	1
2	F.41.14.029.A	Wheel bearing	2	x	1
3	F.41.17.001.A	Brake disc	2	x	1
4	F.41.14.065.A	Lower upright pin	2	x	1
5	F.41.14.066.A	Lower washer, upright pin	2	x	1
6	F.41.14.067.A	Upper washer, upright pin	2	x	1
7	F.41.14.063.B	Spacer, suspension bearing	8	x	1
8	F.41.15.015.A	Rear wishbone mount	2	x	1
9	F.41.14.077.B	Drive peg	8	x	1
10	F.41.14.055.A	Camber shim, 1 mm	2	Option	1
11	F.41.14.056.A	Camber shim, 1.5 mm	2	Option	1
12	F.41.14.057.A	Camber shim, 2 mm	2	x	1
13	F.41.14.058.A	Camber shim, 4 mm	2	Option	1
14	F.41.17.002.A	Brake caliper, trailing left	1	x	1
15	F.41.17.003.A	Brake caliper, trailing right	1	x	1
16	F.41.17.004.A	Brake pads, DS Performance (box of 4)	1	x	1
17	AVM01.12.7062	Screw CHc M12x70 ct62 pitch 150 cl 12.9	4	x	3
18	AVM01.12.7050	Screw CHc M12x70 ct50 pitch 150 cl 12.9	2	x	3
19	AVM01.10.0030	Screw CHc M10x30 cl 12.9	4	x	3
22	AEM01.08.0001	Nylstop nut M8 ZnBl	8	x	3
23	ARO06.08.0001	Washer small Ø8 ZnBl	12	x	3
24	ARO13.08.0001	Washer Schnorr Ø8	4	x	3
26	AVF01.38.0300	Screw CHc 3/8x3" UNF cl 12.9	2	x	3
27	AEF01.38.0001	Nylstop nut 3/8 UNF ZnBl	2	x	3
28	ARO13.12.0001	Washer Schnorr Ø12	6	x	3
29	ARO13.10.0001	Washer Schnorr Ø10	4	x	3
30	AVM06.08.0045	Screw CHc M8x45 full thread cl12.9	4	x	3
31	F.41.17.007.A	Brake pads, DS3000 (box of 4)	1	Option	1




Rear upright

N°	Reference	Description	Qty	Ford	Type
32	F.41.17.008.A	Brake pads, DS1.11 (box of 4)	1	Option	1
33	AVM01.08.5540	Screw CHC M8x55 ct 40 cl 12.9	4	x	3
35	F.41.15.035.A	Rear L/H upright pre assembly	1	Assembly part	1
36	F.41.15.036.A	Rear R/H upright pre assembly	1	Assembly part	1
37	AVM04.06.0016	Screw TFHC M6x16 cl 10.9	2	x	3




Rear wheel

N°	Reference	Description	Qty	Ford	Type
1	F.41.15.026.A	Rear rim	2	x	1
2	F.41.14.082.A	Safety clip, wheel nut	2	x	1
3	F.41.14.079.B	Washer, wheel nut	2	x	1
4	F.41.14.080.A	Wheel nut	2	x	1
5	ACI02.24.0001	External Circlips Ø24	2	x	3
6	F.41.14.081.B	Wheel nut assy	2	Assembly part	1




Steering

N°	Reference	Description	Qty	Ford	Type
1	F.41.16.007.C	Steering rack, complete	1	x	1
3	F.41.16.009.A	Ball joint, steering rack	2	x	1
4	F.41.16.010.A	Rack bush	2	x	1
5	F.41.16.001.B	Steering column	1	x	1
6	F.41.16.019.A	Collapsible device	1	Spare	1
7	F.41.16.020.A	Spacer, collapsible device	1	Spare	1
8	F.41.16.021.A	Screw, collapsible device	1	Spare	3
9	F.41.16.011.A	Shim, steering rack	-	x	3
10	F.41.16.012.A	Locknut, steering rack	2	x	1
11	F.41.16.025.B	Steering column joint assembly	1	x	1
13	F.41.16.002.A	Spherical bearing, steering column	1	x	1
14	F.41.16.026.A	Quick release, steering wheel	1	x	1
15	F.41.16.003.B	Spacer, 10mm, steering wheel	1	Option	1
17	F.41.16.030.A	Steering wheel - optional paddle shift	1	Paddle shift	1
18	F.41.16.033.A	Steering rack bracket	2	x	1
19	F.41.16.032.A	Steering column bracket	1	x	1
21	AVM01.06.0020	Screw CHC M6x20 cl 12.9	2	x	3
22	ARO06.06.0001	Washer small Ø6 ZnBl	4	x	3
25	AVM01.05.0020	Screw CHC M5x20 cl 12.9	3	x	3
26	AVM01.08.0070	Screw CHC M8x70 cl 12.9	4	x	3
27	ARO13.08.0001	Washer Schnorr Ø8	4	x	3
28	ARO06.05.0001	Washer small Ø5 ZnBl	3	x	3
29	ARO06.08.0001	Washer small Ø8 ZnBl	2	x	3
30	AEM01.08.0001	Nylstop nut M8 ZnBl	1	x	3
31	AEM01.06.0001	Nylstop nut M6 ZnBl	1	x	3
32	AEF02.38.0001	Nut 3/8 UNF ZnBl	2	x	3
33	AVM01.06.4534	Screw CHC M6x45 ct 34 cl 12.9	1	x	3
34	AVM01.08.5037	Screw CHC M8x50 ct 37 cl 12.9	1	x	3




Steering

N°	Reference	Description	Qty	Ford	Type
36	F.41.16.036.A	Steering rack, bar	1	Spare	1
37	F.41.16.037.A	Steering rack, spacer	2	x	2
45	F.41.16.046.A	Steering column +80mm	1	Option	1
46	F.41.16.047.A	Steering wheel pallet spacer	2	Option	3




Brake hydraulics

N°	Reference	Description	Qty	Ford	Type
1	F.41.17.010.C	Front brake line	1	x	1
2	F.41.17.012.B	Rear brake line, main	1	x	1
3	F.41.17.013.C	Rear brake line, right	1	x	1
4	F.41.17.014.C	Rear brake line, left	1	x	1
5	AJO01.10.0002	Copper Seal Ø10	4	Spare	3




Monocoque

N°	Reference	Description	Qty	Ford	Type
3	F.41.19.003.A	Nose cap	1	Spare	1
4	F.41.19.002.A	Rear crashbox	1	x	1
7	F.41.19.023.B	Rear roll hoop	1	x	1
8	F.41.19.017.B	Dowel, front crashbox	4	x	1
10	F.41.19.031.B	Bush D12	4	x	1
11	F.41.19.016.B	Rear jack plates (rear crashbox)	2	x	1
12	F.41.18.003.C	Cover plate, extinguisher and battery	1	x	1
13	F.41.18.002.B	Cover plate, fuel tank access	1	x	1
14	F.41.18.007.C	Monocoque	1	x	1
15	F.41.18.005.B	Fuel tank padding	1	x	1
17	F.41.19.019.A	Nose cap clip	4	Spare	1
18	F.41.19.020.A	Nose cap female clip	4	Spare	1
20	F.41.18.009.A	Cable passes	1	x	1
21	F.41.19.057.A	Assembly front crashbox	1	x	1
22	F.41.18.008.A	Monocoque ballast - cockpit 5Kg	3	Option	3
23	F.41.18.010.A	Cockpit ballast bracket	1	Option	3
24	F.41.18.011.A	Monocoque ballast - splitter 2Kg	2	Option	3
25	F.41.18.012.A	Splitter ballast bracket	1	Option	3
26	AVM01.08.6045	Screw CHC M8x60 ct45 cl 12.9	4	x	2
27	AVM01.06.0016	Screw CHC M6x16 cl 12.9	8	x	2
28	ARO13.10.0001	Washer Schnorr Ø10	4	x	3
29	AVM01.05.0020	Screw CHC M5x20 cl 12.9	6	x	3
30	ARO07.05.0001	Washer medium Ø5x12 ZnBI	6	x	3
31	AVM03.05.0012	Screw TBHC M5x12 cl10.9	13	x	3
32	ARO13.08.0001	Washer Schnorr Ø8	4	x	3
34	AVM01.08.0016	Screw CHC M8x16 cl 12.9	4	x	2
35	AVM03.10.0020	Screw TBHC M10x20 cl 10.9	4	x	2
36	ARO06.05.0001	Washer small Ø5 ZnBI	13	x	3




Monocoque

N°	Reference	Description	Qty	Ford	Type
37	AVM01.08.0040	Screw CHC M8x40 cl 12.9	4	Option	3
38	ARO06.08.0001	Washer small Ø8 ZnBl	4	Option	3
39	ARO13.06.0001	Washer Schnorr Ø6	8	x	3
43	F.41.19.058.A	Bracket, front crash box, with captive nut	4	x	1
44	F.41.18.014.A	Knees protection	1	Option	3




Wheel cables

N°	Reference	Description	Qty	Ford	Type
1	F.41.19.034.B	Front wheel cable	2	x	1
2	F.41.19.035.A	Rear wheel cable	2	x	1
3	F.41.19.032.A	Wheel tether shaft, upright	4	x	1
4	F.41.19.033.A	Front wheel tether plate	2	x	1
5	F.41.19.046.A	Shaft, front wheel tether	2	x	1
6	F.41.19.045.A	Bush, front wheel tether	4	x	1
7	F.41.19.037.A	Mounting, rear wheel cable	2	x	1
8	F.41.19.031.B	Bush D12	4	x	1
9	AVM01.08.0040	Screw CHC M8x40 cl 12.9	6	x	3
10	AVM01.05.0030	Screw CHC M5x30 cl 12.9	4	x	3
11	AVM06.08.0045	Screw CHc M8x45 full thread cl12.9	4	x	3
12	ARO06.05.0001	Washer small Ø5 ZnBl	4	x	3
13	ARO13.08.0001	Washer Schnorr Ø8	10	x	3




Head restraint

N°	Reference	Description	Qty	Ford	Type
1	F.41.19.009.C	Head restraint	1	x	1
2	AFC06.00.0003	Camloc Wing Nut 2600-03	2	x	1
3	F.41.19.060.A	Replacement aramid skin, head restraint	1	Repair	1




Extinguisher

N°	Reference	Description	Qty	Ford	Type
1	F.41.19.050.A	Fire extinguisher	1	x	1
2	F.41.19.056.A	Bush, extinguisher cable	1	x	1
5	F.41.21.058.A	Stop sleeve bracket	1	x	1
8	F.41.19.059.A	Extinguisher refill	1	Repair	1
9	F.41.19.061.A	Spacer, extinguisher cable	1	Option	2




Belt and seat

N°	Reference	Description	Qty	Ford	Type
1	F.41.19.030.B	Extractable seat	1	x	2
2	F.41.19.051.B	Upper harness bracket	2	x	1
3	F.41.19.044.A	Kit extraction belts	1	x	1
4	F.41.19.038.A	Harness, 335mm	1	x	1
5	AVM01.06.0020	Screw CHC M6x20 cl 12.9	4	x	2
6	ARO13.06.0001	Washer Schnorr Ø6	4	x	3
7	AVM01.08.0025	Screw CHC M8x25 cl 12.9	4	x	2
8	ARO13.08.0001	Washer Schnorr Ø8	4	x	3
9	ARO06.08.0001	Washer small Ø8 ZnBl	4	x	3




Oil system Ford

N°	Reference	Description	Qty	Ford	Type
1	F.41.20.067.A	Oil tank adaptor Ford	1	x	1
2	F.41.20.021.A	Cap, oil tank adaptor	1	x	1
3	AJO03.73.0262	O Ring Ø72.69x2.62	1	x	3
4	F.41.20.018.A	Bracket, oil radiator	2	Option	1
5	F.41.20.006.B	Oil radiator	1	Option	2
6	AAD02.12.0022	Adapter M22x1.5 / JiC dash 12	2	Option	1
7	F.41.20.070.A	Oil line Ford DASH 12 - OUT oil tank - IN engine	1	x	1
8	F.41.20.072.A	Oil line Ford DASH 12 - OUT engine - IN oil tank	1	x	1
9	F.41.20.076.A	Oil line Ford DASH 12 - OUT radiator	1	Option	1
10	AVM01.06.0016	Screw CHC M6x16 cl 12.9	4	x	3
11	ARO13.06.0001	Washer Schnorr Ø6	4	x	3
12	AVM04.06.0020	Screw TFHC M6x20 cl 10.9	2	Option	3
13	ARO06.06.0001	Washer small Ø6 ZnBl	10	Option	3
14	AEM01.06.0001	Nylstop nut M6 ZnBl	6	Option	3
15	AVM03.06.0020	Screw TBHC M6x20 cl 10.9	4	Option	3
16	F.41.20.075.A	Oil line Ford DASH 12 - IN radiator	1	Option	1
17	ATU01.08.0055	Hose Ø8x12 L55	1	x	3
18	ATU01.05.0400	Hose Ø5,5x8 L400	1	x	3




Catch tank Ford

N°	Reference	Description	Qty	Ford	Type
1	F.41.20.005.A	Catch tank	1	x	1
2	F.41.20.096.A	Bracket, catch tank, Ford	1	x	1
3	ATU01.05.0850	Hose Ø5.5x8 L850	1	x	3
4	ATU01.05.1100	Hose Ø5,5x8 L1100	1	x	3
5	ATU01.05.0900	Hose Ø5,5x8 L900	1	x	3
6	ATU01.08.0055	Hose Ø8x12 L55	2	x	3




Water cooling circuit Ford

N°	Reference	Description	Qty	Ford	Type
1	F.41.20.001.A	Water radiator	1	x	1
2	F.41.20.089.B	Left water radiator, Ford	1	x	1
3	F.41.20.042.A	Header tank 0.7l	1	x	1
4	F.41.20.003.A	Cap, header tank	1	x	3
5	F.41.20.068.A	Bracket, header tank, Ford	1	x	1
6	F.41.20.085.A	Spacer, header tank, Ford	2	x	1
7	F.41.20.090.A	Water outlet, Ford engine	1	x	1
8	F.41.20.091.B	Water inlet, Ford engine	1	x	1
9	F.41.20.043.B	Bracket, water pipe	1	x	1
10	F.41.20.029.B	Water tube, radiators	1	x	1
11	AJO01.22.2701	Copper Seal Ø22-27	1	x	3
12	ARA24.22.0150	Plug M22 x 1,5	1	x	1
13	F.41.20.082.A	Water tube, engine outlet	1	x	1
14	F.41.20.083.A	Water tube, engine inlet	2	x	1
15	F.41.20.094.A	Water tube, header tank	1	x	1
16	AVM03.05.0010	Screw TBHC M5x10 cl10.9	2	x	3
17	ARO06.05.0001	Washer small Ø5 ZnBl	2	x	3
18	F.41.20.026.A	Silicone hose 180° Ø32 resized	1	x	2
19	ADU03.32.0090	Silicone hose 90° Ø32	4	x	2
20	ADU03.32.0045	Silicone hose 45° Ø32	2	x	2
21	ADU03.16.0090	Silicone hose 90° Ø16	1	x	2
22	ADU03.16.0001	Hose Ø16	0.33	x	2
23	F.41.20.046.A	T connection Ø8	1	x	1
24	ADU02.13.0560	Fuel hose Ø13 long 560	1	x	2
25	ADU02.13.0400	Fuel hose Ø13 long 400	1	x	2
26	ADU02.13.0130	Fuel hose Ø13 long 130	1	x	2
27	ACO02.08.0016	Collar Tie Clips Ø8-16	7	x	3
28	ACO02.16.0027	Collar Tie Clips Ø16-27	4	x	3




Water cooling circuit Ford

N°	Reference	Description	Qty	Ford	Type
29	ACO03.32.0050	Collar Tie Clips Ø32-50	14	x	3
30	AVM01.06.0040	Screw CHC M6x40 cl 12.9	2	x	3
31	AEM01.06.0001	Nylstop nut M6 ZnBl	2	x	3
32	ARO06.06.0001	Washer small Ø6 ZnBl	4	x	3
33	AJO03.30.0360	O Ring Ø30.8x3.6	1	x	3
34	AJO03.46.0200	O Ring Ø46x2	1	x	3
35	F.41.20.109.A	Rubber washer Ø16-6.5 thk 3mm	2	x	3




Air circuit Ford

N°	Reference	Description	Qty	Ford	Type
1	F.41.10.099.A	Air box Ford, front part	1	x	2
2	F.41.10.104.A	Air box Ford, rear part	1	x	2
3	F.41.10.066.B	Bracket, air box Ford, left	1	x	1
4	F.41.10.067.B	Bracket, air box Ford, right	1	x	1
5	F.41.10.068.B	Bracket, air box Ford, top	1	x	1
6	F.41.20.074.A	Air tube, intercooler-air intake	1	x	1
7	F.41.20.107.A	Air tube- turbo-intercooler 1	1	x	1
8	F.41.20.079.A	Air tube, turbo-intercooler 2	1	x	1
9	F.41.20.080.A	Air tube, air box-turbo	1	x	1
10	ADU03.38.0045	Silicone hose 45° Ø38	1	x	2
12	ADU03.38.0180	Silicone hose 180° Ø38	1	x	2
13	ADU03.45.3890	Silicone reductor hose 90° Ø45-38	1	x	2
14	ADU03.48.0090	Silicone hose 90° Ø48	1	x	2
15	ADU03.54.4890	Silicone reductor hose 90° Ø54-48	1	x	2
16	ADU03.60.0045	Silicone hose 45° Ø60	1	x	2
17	ADU03.60.0135	Silicone hose 135° Ø60	1	x	2
18	ACO03.00.5070	Collar Tie Clips Ø50-70	9	x	3
19	ACO03.32.0050	Collar Tie Clips Ø32-50	5	x	3
20	AVM01.05.0012	Screw CHC M5x12 cl 12.9	3	x	3
21	AVM01.05.0020	Screw CHC M5x20 cl 12.9	4	x	3
22	AVM01.06.0016	Screw CHC M6x16 cl 12.9	1	x	3
23	AVM03.06.0016	Screw TBHC M6x16 cl 10.9	6	x	3
24	ARO07.05.0001	Washer medium Ø5x12 ZnBl	7	x	3
25	ARO07.06.0001	Washer medium Ø6 ZnBl	13	x	3
26	AEM01.06.0001	Nylstop nut M6 ZnBl	6	x	3




Battery and cables

N°	Reference	Description	Qty	Ford	Type
2	F.41.21.002.A	Battery	1	x	1
6	F.41.21.030.B	Switch plate	1	x	1
7	F.41.21.031.A	Bush, switch plate	2	x	1
8	F.41.21.026.C	Bracket, steering wheel connector	1	x	1
11	F.41.21.042.A	Bracket, park plug	1	x	1
12	F.41.21.006.D	Bracket, battery & extinguisher, right	1	x	1
13	F.41.21.008.C	Bracket, battery, left	1	x	1
14	F.41.21.009.B	Retainer, battery and extinguisher	1	x	1
16	F.41.21.056.A	Bracket, extinguisher retainer	1	x	1
17	F.41.21.057.A	Bracket, master switch contactor	1	x	1
19	F.41.21.060.A	Spring, master switch contactor	1	x	1
21	F.41.21.025.B	Bracket, throttle pedal sensor	1	x	1
22	ACA.06.04.0001	Cable clamp Ø4xØ12 long26	1	x	3
23	AVM01.05.0016	Screw CHC M5x16 cl 12.9	7	x	3
24	AVM01.06.0016	Screw CHC M6x16 cl 12.9	12	x	3
25	AVM01.05.0020	Screw CHC M5x20 cl 12.9	2	x	3
26	AVM01.03.0010	Screw CHC M3x10 cl 12.9	2	x	3
27	AVM03.04.0012	Screw TBHC M4x12 cl 10.9	2	x	3
28	AVM01.04.0025	Screw CHC M4x25 cl 12.9	2	x	3
29	ARO06.05.0001	Washer small Ø5 ZnBI	7	x	3
30	ARO07.05.0001	Washer medium Ø5x12 ZnBI	2	x	3
31	ARO06.06.0001	Washer small Ø6 ZnBI	12	x	3
32	ARO06.03.0001	Washer small Ø3 ZnBI	2	x	3
33	ARO06.04.0001	Washer small Ø4 ZnBI	2	x	3
34	AEM01.04.0001	Nylstop nut M4 ZnBI	4	x	3
35	AEM01.03.0001	Nylstop nut M3 ZnBI	2	x	3
40	F.41.21.101.A	Spacer throttle sensor pedal	1	x	1
41	AVM01.04.0016	Screw CHC M4x16 cl 12.9	1	x	3




Battery and cables

N°	Reference	Description	Qty	Ford	Type
42	ARO07.04.0001	Washer medium Ø4x10 ZnBl	1	x	3
43	AEM01.05.0001	Nylstop nut M5 ZnBl	2	x	3
44	F.41.21.104.A	Long bush, switch plate	2	Option	2




Chassis main loom Ford

N°	Reference	Description	Qty	Ford	Type
1	F.41.21.046.B	Chassis main loom	1	x	1
2	F.41.21.021.B	Throttle pedal sensor	1	x	1
3	F.41.21.084.A	Fuel pump connector	1	x	1
4	F.41.21.085.A	Relay	2	x	1
5	F.41.21.080.A	Master switch relay	1	x	1
6	F.41.21.059.A	Master switch contactor	1	x	1
8	F.41.21.071.A	Switch	3	x	1
9	F.41.21.070.A	Starter push button	1	x	1
10	F.41.21.094.A	Starter to alternator wire	1	x	1
11	F.41.21.093.A	Master switch relay to starter wire	1	x	1
14	F.41.21.090.A	Battery to master switch relay wire	1	x	1
15	F.41.21.096.A	Park plug	1	x	1
16	F.41.21.095.A	Battery ground wire	1	x	1
17	F.41.21.091.A	Rear light with connector	1	x	1
18	F.41.21.092.A	Battery park plug connector	1	Option	1
19	F.41.21.097.A	Battery park plug wire	1	Option	3




Optional parts - Acquisition Ford

N°	Reference	Description	Qty	Ford	Type
1	F.41.21.045.A	Brake pressure sensor	2	Data acquisition	1
2	F.41.17.011.C	Brakes pressure sensor, hydraulic circuit	2	Data acquisition	1
3	F.41.21.048.A	Steering wheel angle sensor	1	Data acquisition	1
4	F.41.21.052.A	Camera	1	Data acquisition	1
5	F.41.21.066.C	Plate on roll hoop, camera bracket	1	Data acquisition	1
6	F.41.21.069.A	Pivot, camera bracket	1	Data acquisition	1
7	F.41.21.073.A	Steering column slotted tub	1	Data acquisition	1
8	F.41.21.049.C	Steering wheel sensor bracket	1	Data acquisition	1
9	F.41.21.004.A	Disc, wheel speed sensor	2	Data acquisition	1
10	F.41.21.003.B	Bracket, wheel speed sensor	2	Data acquisition	1
11	F.41.21.079.A	Spacer, wheel speed sensor bracket	4	Data acquisition	1
12	F.41.21.044.A	Speed wheel sensor	2	Data acquisition	1
13	AVM01.06.0012	Screw CHc M6x12 cl 12.9	2	Data acquisition	3
14	ARO13.06.0001	Washer Schnorr Ø6	2	Data acquisition	3
15	AVM01.05.0016	Screw CHC M5x16 cl 12.9	6	Data acquisition	3
16	AVM01.05.0030	Screw CHC M5x30 cl 12.9	2	Data acquisition	3
17	AVM03.05.0012	Screw TBHC M5x12 cl10.9	1	Data acquisition	3
18	ARO06.05.0001	Washer small Ø5 ZnBl	6	Data acquisition	3
19	ARO07.05.0001	Washer medium Ø5x12 ZnBl	3	Data acquisition	3
20	F.41.21.081.A	Life Racing Ford GPS	1	Data acquisition	1
21	F.41.21.082.A	ECU Bridge (Smarty cam / ECU life Racing)	1	Data acquisition	1
22	F.41.21.099.A	GPS Life Racing harness	1	Data acquisition	1
23	F.41.21.100.A	Lap trigger	1	Data acquisition	1




Gear shift paddle - Gearbox Ford

N°	Reference	Description	Qty	Ford	Type
1	F.41.12.060.A	Gearbox, Ford, paddle shift	1	Paddle shift	1
3	F.41.12.072.A	Closing plate, reverse gear, paddle shift	1	Paddle shift	1
4	F.41.12.059.A	Clutch shaft - Ford engine	1	Spare	1
5	AVM04.06.0035	Screw TFHC M6x35 cl 10.9	4	Paddle shift	3
6	AVM01.06.0016	Screw CHC M6x16 cl 12.9	5	Paddle shift	3
7	AVM01.06.4028	Screw CHC M6x40 ct 28 cl 12.9	1	Paddle shift	3
8	ARO06.06.0001	Washer small Ø6 ZnBl	11	Paddle shift	3
9	AEM01.06.0001	Nylstop nut M6 ZnBl	5	Paddle shift	3
10	F.41.12.128.A	Extension selector rocker (paddle shift)	1	Paddle shift	1
11	F.41.12.069.A	Manual gearbox lever	1	Paddle shift	1
12	F.41.12.129.A	O ring Ø12x2	1	Paddle shift	3




Gear shift paddle - Actuator Ford

N°	Reference	Description	Qty	Ford	Type
1	F.41.12.034.A	Compressor	1	Spare	1
2	F.41.12.078.A	Screw TBHC M5x20	4	Spare	3
3	F.41.12.079.A	Bracket + tank kit	1	Spare	1
4	F.41.12.035.A	Valve	2	Spare	1
5	F.41.12.080.A	Filter	2	Spare	1
6	F.41.12.081.A	Screw CHC M4x8 + 4 Schnorr washers	4	Spare	3
7	F.41.12.082.A	Solenoid valve	2	Spare	1
8	F.41.12.083.A	Valves bracket	1	Spare	1
9	F.41.12.084.A	Air collector	1	Spare	1
10	F.41.12.085.A	Air collector seal Ø13x18	4	Spare	3
11	F.41.12.086.A	Silent block	3	Spare	1
12	F.41.12.087.A	Silent-block nut M5	6	Spare	3
13	F.41.12.123.A	Pneumatic hose kit	1	Paddle shift	1
14	F.41.12.089.A	Hose connection kit	1	Spare	1
15	F.41.12.090.A	Air pressure sensor	1	Spare	1
16	F.41.12.091.A	Pneumatic hose tank to valve lg 200	1	Spare	1
17	F.41.12.121.A	Pneumatic jack hose upshift lg 900	1	Spare	1
18	F.41.12.122.A	Pneumatic jack hose downshift lg 1000	1	Spare	1
19	F.41.12.094.A	Hose connection JM 7/16 - 1/4	4	Spare	1
20	F.41.12.095.A	Banjo connection 1/4 BSP	2	Spare	1
21	F.41.12.096.A	Paddle-shift module assembly	1	Paddle shift	1
22	F.41.12.097.A	Air filter assembly	1	Spare	1
23	F.41.12.098.A	Air filter	1	Spare	1
24	F.41.12.024.A	Pneumatic jack	1	Spare	1
25	F.41.12.071.A	Ball joint	1	Spare	1
26	F.41.12.099.A	Ball joint adapter	1	Spare	1
27	F.41.12.023.A	Jack bracket	1	Spare	1
28	F.41.12.073.A	Rear Jack base	1	Spare	1




Gear shift paddle - Actuator Ford

N°	Reference	Description	Qty	Ford	Type
29	F.41.12.100.A	Jack pin	1	Spare	3
30	F.41.12.101.A	Hose connection JM 7/16 - 1/8	2	Spare	1
31	F.41.12.102.A	Pneumatic jack assembly	1	Paddle shift	1




Gearbox - Ratios

N°	Reference	Description	Qty	Ford	Type
1	F.41.12.111.A	Dog ring, Gearbox	3	Spare	1
2.01	F.41.12.112.A	Ratio 14/37, Gearbox	1	Spare	1
2.02	F.41.12.113.A	Ratio 18/35, Gearbox	1	Spare	1
2.03	F.41.12.114.A	Ratio 18/28, Gearbox	1	Spare	1
2.04	F.41.12.115.A	Ratio 21/27, Gearbox	1	Spare	1
2.05	F.41.12.116.A	Ratio 20/22, Gearbox	1	Spare	1
2.06	F.41.12.117.A	Ratio 27/26, Gearbox	1	Spare	1
2.07	F.41.12.118.A	Ratio 22/29, Gearbox	1	Option	1
2.08	F.41.12.119.A	Ratio 24/28, Gearbox	1	Option	1
2.09	F.41.12.120.A	Ratio 22/23, Gearbox	1	Option	1




Fuel cell

N°	Reference	Description	Qty	Ford	Type
1	F.41.23.001.A	Fuel tank	1	x	1
2	F.41.23.003.B	Fuel tank foam	1	Spare	1
3	F.41.23.011.D	Fuel tank plate, front	1	x	1
4	F.41.23.017.B	Fuel tank seal, front	1	Spare	1
5	F.41.23.013.D	Fuel tank plate, rear	1	x	1
6	F.41.23.016.A	Fuel tank seal, rear	2	Spare	1
10	AJO03.34.0360	O Ring Ø34.1x3.6	1	x	3
11	F.41.23.019.B	Cable gland, front fuel plate	1	Spare	1
13	F.41.23.040.B	Nut, cable gland, front fuel plate	1	Spare	3
14	F.41.23.041.B	Seal, cable gland, front fuel plate	2	Spare	3
15	AVM01.05.0016	Screw CHC M5x16 cl 12.9	18	x	3
16	AVM01.04.0020	Screw CHC M4x20 cl 12.9	12	x	3
17	ARO06.05.0001	Washer small Ø5 ZnBI	18	x	3
18	ARO06.04.0001	Washer small Ø4 ZnBI	12	x	3
19	F.41.23.045.A	Fuel cap with breather	1	x	1




Fuel pump system Ford

N°	Reference	Description	Qty	Ford	Type
1	F.41.23.042.A	Fuel tank buffer assembly - Ford engine	1	Assembly part	1
2	ARA23.00.0006	Female plug 9/16x18 (Dash6)	2	x	1
3	F.41.23.034.A	Fuel pump	1	x	1
4	F.41.23.039.A	4.5 fuel regulator pressure	2	x	1
5	F.41.23.033.A	Fuel tank buffer check valve	3	Spare	1
6	F.41.23.038.A	Filter sock 340 series	1	x	1
7	ACO02.08.0016	Collar Tie Clips Ø8-16	9	x	3
8	ACO03.06.0006	P clips M6 Ø6	1	x	3
9	ADU02.13.0800	Fuel hose Ø13 long 800	1	x	3
10	ADU02.13.0500	Fuel hose Ø13 long 500	3	x	3
11	ADU02.13.1800	180° fuel hose Ø13	1	x	3
12	F.41.23.050.A	Break-away coupling male	1	x	1
13	F.41.23.051.A	Break-away coupling female	1	x	1
14	F.41.23.046.B	Fuel tank buffer body with check valves	1	x	1
15	F.41.23.026.C	Assembly regulator bracket	1	x	1
16	F.41.23.018.D	Fuel pump wiring	1	x	1
17	AVM11.04.0010	Screw TBHc M4x10 cl 10.9 ZnBl	6	x	3
18	ARO07.04.0001	Washer medium Ø4x10 ZnBl	2	x	3
19	ACO01.00.0003	Rilsan 203x3,6	2	x	3
20	F.41.23.052.A	Fuel filter	1	x	1
21	F.41.23.053.A	Ø8 male connection	1	x	1
22	F.41.23.044.A	Fuel hose	1	x	1




Sidepods

N°	Reference	Description	Qty	Ford	Type
11	AVM03.05.0012	Screw TBHC M5x12 cl10.9	8	x	3
12	AFC02.00.0001	Camloc receptacle	14	Spare	3
13	AVM04.05.0020	Screw TFHC M5x20 cl 10.9	12	x	3
14	AVM01.05.0016	Screw CHC M5x16 cl 12.9	8	x	3
15	ARO07.05.0001	Washer medium Ø5x12 ZnBl	28	x	3
16	AEM01.05.0001	Nylstop nut M5 ZnBl	12	x	3
17	AFC07.00.0001	Camloc Washer	18	Spare	3
18	AFC05.00.0007	Camloc 7D	14	Spare	3
19	AFC05.00.0005	Camloc 5D	4	Spare	3
20	F.41.26.067.A	Bracket, sidepod on floor, with recptacle	6	x	1
21	F.41.26.068.A	Front bracket, sidepod on monocoque, with receptacle	2	x	1
22	F.41.26.069.A	Rear bracket, sidepod on monocoque, with receptacle	2	x	1
23	F.41.26.075.A	Rear side pod, with camlocs, left	1	x	2
24	F.41.26.074.A	Rear side pod, with camlocs, right	1	x	2
25	F.41.26.078.A	Front side pod, with camlocs, left	1	x	2
26	F.41.26.077.A	Front side pod, with camlocs, right	1	x	2




Floor

N°	Reference	Description	Qty	Ford	Type
1	F.41.26.004.A	Skid bloc	1	x	1
2	F.41.26.015.A	Wood floor evo	1	x	1
4	F.41.26.011.A	Splitter, with fixings	1	x	2
5	F.41.26.028.A	Front tie rod, flat floor	2	x	1
6	F.41.26.035.A	Middle tie rod, flat floor, left	1	x	1
7	F.41.26.034.A	Middle tie rod, flat floor, right	1	x	1
10	F.41.26.048.B	Front flat floor, with fixings	1	x	2
11	F.41.26.049.C	Rear flat floor, with fixings	1	x	2
13	F.41.26.053.B	Flat floor centering pin	4	x	1
14	AVM04.05.0020	Screw TFHC M5x20 cl 10.9	7	x	3
15	AVM04.05.0025	Screw TFHC M5x25 cl 10.9	31	x	3
16	AVM01.05.0016	Screw CHC M5x16 cl 12.9	4	x	3
17	ARO07.05.0001	Washer medium Ø5x12 ZnBl	8	x	3
19	AEM01.05.0001	Nylstop nut M5 ZnBl	9	x	3
20	AVM01.05.0020	Screw CHC M5x20 cl 12.9	5	x	3




Covers and accessories

N°	Reference	Description	Qty	Ford	Type
3	F.41.26.040.A	Windscreen	1	x	1
4	F.41.19.021.B	Rear view mirror, left	1	x	1
5	F.41.19.022.B	Rear view mirror, right	1	x	1
12	F.41.26.046.B	Wheel tether cover, front	2	x	2
13	F.41.26.047.B	Wheel tether cover, rear	2	x	2
14	AVM01.05.0010	Screw CHc M5x10 cl 12.9	8	x	3
15	AVM01.05.0016	Screw CHC M5x16 cl 12.9	8	x	3
16	ARO07.05.0001	Washer medium Ø5x12 ZnBl	12	x	3
18	AFC05.00.0003	Camloc 3D	4	Spare	3
19	AFC05.00.0005	Camloc 5D	8	Spare	3
20	AFC05.00.0007	Camloc 7D	6	Spare	3
21	AFC07.00.0001	Camloc Washer	16	Spare	3
22	AVM01.06.0045	Screw CHC M6x45 cl 12.9	2	x	3
23	AVM03.04.0008	ScrewTBHC M4x08 cl 10.9	5	x	3
24	ARO07.04.0001	Washer medium Ø4x10 ZnBl	5	x	3
25	F.41.26.070.A	Bracket, engine cover, with receptacle	2	x	1
26	F.41.26.066.A	Upper bracket, engine cover on monocoque, with receptacle	4	x	1
27	F.41.26.071.A	Rear bracket, engine cover on gearbox, left, with receptacle	1	x	1
28	F.41.26.072.A	Rear bracket, engine cover on gearbox, right, with receptacle	1	x	1
29	F.41.26.073.A	Front cover, with camlocs	1	x	2
30	F.41.26.076.A	Rear cover, with camlocs	1	x	2
31	AVM01.08.0012	Screw CHC M8x12 cl 12.9	4	x	3
32	ARO06.08.0001	Washer small Ø8 ZnBl	4	x	3




Bodywork equipment Ford

N°	Reference	Description	Qty	Ford	Type
1	F.41.26.017.B	Radiator air duct, right	1	x	2
2	F.41.26.063.B	Radiator air duct, left, Ford	1	x	2
4	AVM01.05.0012	Screw CHC M5x12 cl 12.9	13	x	3
5	AVM04.05.0025	Screw TFHc M5x25 cl 10.9	2	x	3
6	ARO07.05.0001	Washer medium Ø5x12 ZnBl	15	x	3
7	AEM01.05.0001	Nylstop nut M5 ZnBl	2	x	3
8	F.41.26.064.A	Rear tie rod, flat floor, left, Ford	1	x	1
9	F.41.26.065.A	Rear tie rod, flat floor, right, Ford	1	x	1
10	F.41.26.081.A	Grille, radiator protection	1	Option	1
11	F.41.26.082.A	Grille, radiator protection left, Ford	1	Option	1



Wings

N°	Reference	Description	Qty	Ford	Type
1	F.41.24.001.B	Rear wing mount	2	x	1
2	F.41.24.002.A	Lower rear wing	1	x	1
3	F.41.24.003.A	Upper rear wing	1	x	1
4	F.41.24.004.A	Rear end plate	2	x	1
5	F.41.24.005.A	Front end plate	2	x	1
7	F.41.24.007.C	Front wing mount, right	1	x	1
8	F.41.24.008.C	Front wing mount, left	1	x	1
9	F.41.24.009.E	Front wing gurney	2	Spare	1
10	AVM03.06.0016	Screw TBHC M6x16 cl 10.9	18	x	3
11	ARO07.06.0001	Washer medium Ø6 ZnBl	20	x	3
12	AVM03.06.0020	Screw TBHC M6x20 cl 10.9	6	x	3
13	AVM01.08.0025	Screw CHC M8x25 cl 12.9	4	x	3
14	AVM01.08.0030	Screw CHc M8x30 cl 12.9	4	x	2
15	ARO06.08.0001	Washer small Ø8 ZnBl	12	x	3
16	ARO06.06.0001	Washer small Ø6 ZnBl	8	x	3
18	AEM01.06.0001	Nylstop nut M6 ZnBl	4	x	3
19	AEM01.08.0001	Nylstop nut M8 ZnBl	4	x	3
20	F.41.24.011.A	Front wing with gurney	1	x	1



Tooling and accessories

N°	Reference	Description	Qty	Ford	Type
1	F.41.35.008.C	Front jack assembly	1	Option	3
2	F.41.35.026.B	Parallelism Front bar assembly	1	Option	3
12	F.41.35.027.B	Parallelism Rear bar assembly	1	Option	3
13	F.41.35.020.B	Rear jack	1	Option	3
14	F.41.35.060.B	Wrench for wheel studs	1	Option	3
15	F.41.35.124.A	Wheel peg tightening socket	1	Option	3
18	F.41.35.054.A	Trestles bodywork support	1	Option	3
19	F.41.35.064.A	Steering rack stop	2	Option	3
20	F.41.35.001.A	Ride height adjustment pinule	2	Option	3
21	F.41.35.066.A	Full false wheel	4	Option	3
23	F.41.35.105.A	Filling cask	1	Option	3
24	F.41.35.033.A	10mm wedge for false wheel	4	Option setup	3
25	F.41.35.035.A	2mm wedge for false wheel	4	Option setup	3
26	F.41.35.032.A	1mm wedge for false wheel	4	Option setup	3
27	F.41.35.110.A	Filling cask support	1	Option	3
28	F.41.35.120.A	Locking plate, Gearbox tooling	1	Option	3
29	F.41.35.121.A	Play adjuster, Gearbox tooling	1	Option	3
30	F.41.35.122.A	Spacer, Gearbox tooling	1	Option	3
31	F.41.35.123.A	Primary bolt tool, Gearbox tooling	1	Option	3
33	F.41.35.127.A	Steering wheel assembly support	1	Option	3
34	F.41.35.155.C	Transportation kit without engine, Ford	1	Option	3

False wheels set-up indication for Hankook		
	Front (mm)	Rear (mm)
Tyre radius (loaded)	273*	280*
Necessary shims height	21	28
Necessary shims ref/wheel	2x F.41.35.033.A + F.41.35.032.A	2x F.41.35.033.A + 4x F.41.35.035.A

* depending on pressure, camber, weight and distribution

Type 1:

These parts must be supplied by the manufacturer and used exactly as supplied. Repairs may be carried out only by the manufacturer.

Type 2:

These parts are Type 1 parts with specific restrictions. Only the modifications indicated in the homologation may be carried out. Repairs are allowed only in the described range. For the allowed modifications detail, see the user manual.

Type 3:

These parts are unrestricted, provided they are used as designed by the manufacturer and do not fulfil any additional function.